



型號：DH-3013
品名：刮平刀
規格：25.8x5.5x1.1cm



型號：DH-7059
品名：矽膠料理刷P
規格：21.5x4x1.6cm



型號：DH-7111/7113
品名：刮平刀
規格：25x5.1x1cm(7111)/
24.8x5.3x1cm(7113)



型號：DH-7112
品名：刮平刀(小)
規格：19.8x3.4x1.5cm



停產
尚有庫存

型號：DH-7115
品名：可拌炒刮平鏟(黃)
規格：27.2x5.8x1.8cm



型號：DH-7324
品名：矽膠刮皮刀(P)
規格：26x5.3x1.2cm



型號：DS-1009
品名：矽膠塗油刷(Y)
規格：21.5x4x1.6cm



型號：DZ-0759
品名：蔬菜脫水器
規格：16(含柄寬21)x20cm



型號：HMA-01
品名：拉拉轉蔬菜切碎器
規格：12.5x9.5cm



型號：102-239-011
品名：易拉轉蔬菜切碎器
規格：13.5x13cm



型號：DA-5032
品名：迷你蔬菜切碎器
規格：12x12.4cm



型號：DA-1210
品名：蔬菜脫水器
規格：22.5x17cm



型號：DH-7220
品名：蔬菜脫水切碎機
規格：18.8x26cm



型號：L23200
品名：蔬菜脫水機
規格：29x19cm




型號：SP1194
品名：蔬菜脫水器(小)
規格：19x12cm



型號：SP1195
品名：蔬菜脫水器(大)
規格：26x16cm

削菜機



手搖削菜機
34.5x12.7x24cm



削菜機刀片(細目)
6.5x2cm

削菜機刀片(中目)
6.5x2cm

削菜機刀片(粗目)
6.5x2cm

削菜機刀片(平目)
9x2.5cm



平面削菜機S
31.5x9x2.4cm



NO95
27x11.5x16.8cm



NO120
32.6x16x5cm



CHIBA
網型削菜機(四用)
24.5x23x17cm



型號：200316
品名：1排肉筋叉(16針)
規格：14x2.6x10cm



型號：200345NS
品名：營業用肉筋叉
(可拆式)
規格：15x4.4x11.5cm



型號：200348
品名：營業用肉筋叉
規格：14.2x3.7x10cm



型號：MT-160G
品名：單排肉筋叉
規格：13x13x2cm



型號：MT-160W
品名：單排肉筋叉
規格：13x13x2cm



型號：MT-160Y
品名：單排肉筋叉
規格：13x13x2cm



型號：10328
品名：2排肉筋叉(22針/粉)
規格：12.3x12.3x3cm



型號：10329
品名：2排肉筋叉(22針/藍)
規格：12.3x12.3x3cm