



型號：DL-0130
品名：不沾蛋糕模 18CM
規格：19 x 19 x 6 cm



型號：DL-0131
品名：不沾蛋糕模 20CM
規格：21 x 21 x 5.5 cm



型號：DL-0132
品名：不沾蛋糕模 22CM
規格：23 x 23 x 5.5 cm



型號：DL-0133
品名：土司蛋糕模 20CM
規格：21 x 12 x 7.5 cm



型號：DL-0134
品名：土司蛋糕模 25CM
規格：26 x 12 x 7.5 cm



型號：DL-0140
品名：15cm 中空不沾蛋糕模
規格：15.5 x 15.5 x 5.4 cm



型號：DL-0141
品名：18cm 中空不沾蛋糕模
規格：18.5 x 18.5 x 5.4 cm



型號：DL-0142
品名：心型蛋糕模
規格：13.5 x 14.5 x 3.5 cm



型號：DL-0143
品名：心型蛋糕模
規格：17.5 x 18.5 x 3.5 cm



型號：DL-0144
品名：不沾點心模 (8cm)
規格：8 x 8 x 2 cm



型號：DL-0146
品名：不沾點心模 XL
規格：9 x 9 x 5.5 cm



型號：DL-0147
品名：不沾點心模 L
規格：8.5 x 8.5 x 3.5 cm



型號：DL-0148
品名：不沾點心模 M
規格：7.5 x 7.5 x 3.5 cm



型號：DL-0153
品名：麵包模 (大)
規格：25.7 x 9.1 x 6.2 cm



型號：DL-0154
品名：麵包模 (中)
規格：21.5 x 8.7 x 6 cm



型號：DL-0155
品名：麵包模 (小)
規格：17.8 x 8.7 x 6 cm



型號：DL-0319
品名：馬口鐵派模(3入)
規格：8 x 8 x 2 cm



型號：DL-0320
品名：馬口鐵派模(3入)
規格：10 x 10 x 2 cm



型號：DL-0331
品名：麵粉篩(大)
規格：16 x 10 x 11 cm



型號：DL-0333
品名：平底篩籃
規格：19.5 x 19.5 x 5.5 cm



型號：DL-0334
品名：平底篩籃
規格：16 x 16 x 5.5 cm



型號：DL-0337
品名：麵粉桿
規格：35.8 x 3 x 3 cm



型號：DL-0345
品名：計量匙 3 支組
規格：16.5 x 4.5 x 2 cm



型號：DL-0356
品名：餅乾模組 6 款入
規格：13.5 x 10 x 1.2 cm



型號：DL-0362
品名：奶油嘴 + 擠奶油袋組
規格：12 x 9.5 x 1.5 cm



型號：DL-0380
品名：布丁模 L
規格：7.5 x 7.5 x 4 cm



型號：DL-0381
品名：布丁模 M
規格：7 x 7 x 4.5 cm



型號：DL-0382
品名：布丁模 S
規格：7 x 7 x 3.5 cm



型號：DL-0383
品名：果凍模(富士山)
規格：8.5 x 8.5 x 5 cm



型號：DL-0384
品名：果凍模(菊)
規格：7.5 x 7.5 x 3.5 cm



型號：DL-0385
品名：果凍模(梅)
規格：7.5 x 7.5 x 3.5 cm



型號：DL-0396
品名：心型壓模 5 入
規格：11.5 x 12 x 20 cm



型號：DL-0430
品名：捲筒蛋糕鋪紙
規格：36 x 700 cm



型號：DL-0441
品名：深型不銹鋼料理盆
規格：23 x 23 x 11 cm



型號：DL-0442
品名：深型不銹鋼料理盆
規格：26 x 26 x 13 cm



型號：DL-0468
品名：奶油嘴 6 入
規格：6.5 x 2 x 5.5 cm



型號：DL-0478
品名：舟型鋁箔紙 (厚 20 入)
規格：10.5 x 6.5 x 2.5 cm



型號：DL-0480
品名：菊型鋁箔紙 (厚 20 入)
規格：7 x 7 x 3 cm



型號：DL-0526
品名：不沾中空蛋糕模
規格：16.5 x 16.5 x 10 cm



型號：DL-0238
品名：不沾中空蛋糕模
規格：19.5 x 19.5 x 12 cm



型號：DL-0528
品名：不沾中空蛋糕模
規格：22.5 x 22.5 x 12 cm



型號：DL-0435
品名：13 cm 不銹鋼計量杯
規格：21 x 15.5 x 6.5 cm



型號：DL-0530
品名：烘焙紙
規格：23.5 x 30.5 cm



型號：DL-0593
品名：巧克力鋁箔模 40 入
規格：3.5 x 3.5 x 2 cm



型號：DL-0594
品名：巧克力紙模 40 入
規格：3 x 3 x 2.5 cm



型號：DL-0626
品名：計量杯 200ml
規格：7.5 x 11.8 x 7.2 cm



型號：DL-0655
品名：蛋糕旋轉台
規格：27.5 x 27.5 x 2 cm



型號：DL-0869
品名：心型壓模 3 入
規格：8 x 8 x 3 cm



型號：DL-0967
品名：蛋糕用溫度計 0-100°C
規格：31 x 1.3 x 1.3 cm



型號：DL-5105
品名：厚度控制麵粉桿
規格：36 x 3.8 x 3.8 cm



型號：DL-5110
品名：脫模刀
規格：22.2 x 2.4 x 0.8 cm



型號：DL-5116
品名：蛋糕鏟
規格：24.3 x 5.1 x 2.8 cm



型號：DL-5117
品名：蛋糕刀
規格：25 x 2.3 x 1 cm



型號：DL-5140
品名：餅乾模組 (6 款入)
規格：13.8 x 9.8 x 1.2 cm



型號：DL-5136
品名：派石
規格：約 300g



型號：DL-5548
品名：奶油嘴 (直)
規格：1.8 X 1.8 X 7 cm



型號：DL-5144
品名：造型壓餅模器 (鳥.熊.魚)
規格：16.5 x 8.5 x 5.3 cm



型號：DL-5145
品名：動物造型餅乾模 6 款
規格：13.6 x 8.7 x 3.8 cm



型號：DL-5203
品名：打蛋器 (廚師專用)
規格：35 x 8 x 8 cm



型號：DL-5204
品名：橡皮刮刀
規格：25 x 5 x 1 cm



型號：DL-5206
品名：木鏟
規格：30 x 5.3 x 1.2 cm



型號：DL-5207
品名：橡皮刮刀
規格：18 x 9.5 x 1.5 cm



型號：DL-5208
品名：巧克力用溫度計 0-100°C
規格：29.5 x 2.5 x 0.8 cm



型號：DL-5209
品名：不銹鋼切麵刀
規格：10.5 x 12.5 x 2.5 cm



型號：DL-5210
品名：塗料毛刷 (M)
規格：18 x 4.5 x 1 cm



型號：DL-5211
品名：塗料毛刷 (L)
規格：18 x 5.5 x 1 cm



型號：DL-5222
品名：蛋糕刀 (27.5cm)
規格：40 x 3 x 2.5 cm



型號：DL-5266
品名：15 cm 威風中空蛋糕模
規格：17 x 17 x 10 cm



型號：DL-5267
品名：18 cm 威風中空蛋糕模
規格：19 x 19 x 12 cm



型號：DL-5268
品名：21 cm 威風中空蛋糕模
規格：22 x 22 x 12.5 cm



型號：DL-5504
品名：餅乾模 (臘腸狗)
規格：3.4 x 5.8 x 1.8 cm



型號：DL-5505
品名：餅乾模 (雪納瑞)
規格：5 x 6.5 x 1.8 cm



型號：DL-5506
品名：餅乾模 (兔顏)
規格：3.2 x 4.8 x 1.8 cm



型號：DL-5507
品名：餅乾模 (小兔)S
規格：3.4 x 4.5 x 1.8 cm



型號：DL-5508
品名：餅乾模 (小兔)L
規格：5.8 x 6 x 1.8 cm



型號：DL-5509
品名：餅乾模 (人型)L
規格：5.1 x 3.2 x 1.8 cm



型號：DL-5510
品名：餅乾模 (小熊)S
規格：3.8 x 3.5 x 1.8 cm



型號：DL-5511
品名：餅乾模 (小熊)L
規格：5.3 x 4.6 x 1.8 cm



型號：DL-5512
品名：餅乾模 (小鳥)
規格：3.1 x 4.9 x 1.8 cm



型號：DL-5513
品名：餅乾模 (小魚)
規格：2.2 x 3 x 1.8 cm



型號：DL-5514
品名：餅乾模 (花)
規格：4 x 4 x 2.6 cm



型號：DL-5515
品名：餅乾模 (菊)
規格：4 x 4 x 2.6 cm



型號：DL-5517
品名：餅乾模 (櫻花)
規格：4 x 4 x 2.6 cm



型號：DL-5518
品名：餅乾模 (人型)S
規格：4.4 x 5 x 1.8 cm



型號：DL-5520
品名：餅乾模 (星星)
規格：3.5 x 3.5 x 1.8 cm



型號：DL-5521
品名：餅乾模 (星星)
規格：4.5 x 4.5 x 1.8 cm



型號：DL-5523
品名：餅乾模 (大象)
規格：5 x 7 x 1.8 cm



型號：DL-5524
品名：餅乾模 (鬱金香)
規格：5 x 5.2 x 1.8 cm



型號：DL-5525
品名：餅乾模 (樹)
規格：6.3 x 4.5 x 1.8 cm



型號：DL-5526
品名：餅乾模 (貓咪)
規格：3.1 x 4.3 x 1.8 cm



型號：DL-5528
品名：餅乾模 (愛心)
規格：3 x 2.8 x 1.8 cm




型號：DL-5529
品名：餅乾模 (愛心)
規格：4 x 3.8 x 1.8 cm



型號：DL-5530
品名：餅乾模 (飛機)
規格：4.7 x 4.5 x 1.8 cm



型號：DL-5531
品名：餅乾模 (船)
規格：5 x 3.3 x 1.8 cm



型號：DL-5550
品名：22cm 圓型蛋糕散熱架
規格：22 x 22 x 2.5 cm



型號：DL-5551
品名：25cm 圓型蛋糕散熱架
規格：25 x 25 x 2.5 cm



型號：DL-5549
品名：不沾烤盤
規格：30 x 22 x 2.5 cm



型號：DL-5552
品名：刮片
規格：9.7 x 12.2 x 0.2 cm



型號：DL-5559
品名：製果用溫度計 0-50°C
規格：16.4 x 1.3 x 1.3 cm



型號：DL-5560
品名：木鏟
規格：25 x 4.6 x 8 cm



型號：DL-5561
品名：麵包切痕刀
規格：18 x 1.3 x 0.5 cm



型號：DL-5568
品名：吐司模附蓋 (1斤)
規格：23.1 x 10.9 x 9.3 cm



型號：DL-5569
品名：吐司模附蓋 (1.5斤)
規格：24.8 x 12.3 x 13 cm



型號：DL-5570
品名：慕斯模 (6CM)
規格：6.1 x 6.1 x 4.5 cm



型號：DL-5571
品名：慕斯模 (9 cm)
規格：9.1 x 9.1 x 4.5 cm



型號：DL-5572
品名：慕斯模 (12CM)
規格：12.1 x 12.1 x 4.5 cm



型號：DL-5573
品名：慕斯模 (15CM)
規格：15.1 x 15.1 x 4.5 cm




型號：DL-5574
品名：慕斯模 (18CM)
規格：18.1 x 18.1 x 4.5 cm



型號：DL-5580
品名：馬芬蛋糕模 (6 格)
規格：27 x 18 x 3.3 cm



型號：DL-5586
品名：底盤可脫式派盤
規格：12 x 12 x 2.6 cm



型號：DL-5587
品名：底盤可脫式派盤
規格：15 x 15 x 3 cm



型號：DL-5590
品名：底盤可脫式蛋糕模
規格：10 x 10 x 5 cm



型號：DL-5592
品名：底盤可脫式蛋糕模
規格：15 x 15 x 6 cm



型號：DL-5593
品名：底盤可脫式蛋糕模
規格：18 x 18 x 6 cm



型號：DL-5594
品名：底盤可脫式蛋糕模
規格：20 x 20 x 5.7 cm



型號：DL-5606
品名：打蛋器
規格：7.5 x 8 x 37.3 cm



型號：DL-5611
品名：不銹鋼抹平刀
規格：2.8 x 2.8 x 30 cm



型號：DL-5612
品名：不銹鋼抹平刀
規格：3.5 x 3.2 x 34.5 cm



型號：DL-5846
品名：方型電子秤(粉)2KG
規格：16 x 9.8 x 2 cm



型號：DL-5847
品名：方型電子秤(綠)2KG
規格：16 x 9.8 x 2 cm



型號：DL-5850
品名：圓型矽膠冰棒模
規格：12.2 x 4.5 x 10 cm



型號：DL-5851
品名：愛心矽膠冰棒模
規格：12.2 x 4.5 x 10 cm



型號：DL-5852
品名：花型矽膠冰棒模
規格：12.2 x 4.5 x 10 cm



型號：DL-5853
品名：方型矽膠冰棒模
規格：12.2 x 4.5 x 10 cm



型號：DL-5854
品名：星星矽膠冰棒模
規格：12.2 x 4.5 x 10 cm



型號：DL-5900
品名：好清理透明按壓粉篩
規格：15 x 12 x 14.5 cm



型號：DL-5902
品名：矽膠刮平刀 S
規格：20.2 x 3.3 x 0.8 cm



型號：DL-5903
品名：矽膠刮平刀 L
規格：25 x 6 x 1.1 cm



型號：DL-5904
品名：矽膠料理刷(紅)
規格：21.5 x 4.1 x 1.7 cm



型號：DL-5920
品名：矽膠打蛋器
規格：26.7 x 6.7 x 6.7 cm



型號：DL-5921
品名：矽膠打蛋器
規格：32 x 7 x 7 cm



型號：DL-5933
品名：矽膠打蛋器
規格：38 x 8.2 x 8.2 cm



型號：DL-5930
品名：烘焙專用矽膠墊
規格：26x36 cm




型號：DL-5926
品名：可收納電子秤0.5~2KG
規格：13.5 x 10.8 x 1.8 cm



型號：DL-5938
品名：烘焙紙
規格：23.5 x 30.5 cm



型號：DL-5940
品名：刮片(白)
規格：12 x 9.5 x 0.1 cm



型號：DL-5941
品名：刮片(紅)
規格：12 x 9.5 x 0.1 cm



型號：DL-5965
品名：餅乾模(貓/3款入)
規格：8 x 3.2 x 2.5 cm



型號：DL-5966
品名：餅乾模(狗/3款入)
規格：6.2 x 5.2 x 2.3 cm



型號：DL-5967
品名：長方型大烤盤
規格：36.5 x 25 x 1.9 cm




型號：DL-5968
品名：底盤可脫長型蛋糕模
規格：21.2 x 6.7 x 5.6 cm



型號：DL-5970
品名：底部可取方型蛋糕模
規格：19.2 x 19.2 x 4.7 cm



型號：DL-5971
品名：不銹鋼刮平/脫模刀
規格：28.5 x 1.8 x 2.2 cm



型號：DL-5974
品名：正方形散熱架 30 cm
規格：30 x 30 x 2.5 cm



型號：DL-5976
品名：擠奶油器 (8種花樣)
規格：18.5 x 6.2 x 4.1 cm



型號：DL-5981
品名：甜甜圈模 (圓型6取)
規格：26 x 18 x 3.4 cm



型號：DL-5982
品名：甜甜圈模 (波浪型6取)
規格：26 x 18 x 3.6 cm



型號：DL-5993
品名：吉拿棒模 (心型2取)
規格：26 x 11.2 x 1.2 cm



型號：DL-5994
品名：吉拿棒模 (長條3取)
規格：26 x 11.2 x 1.2 cm



型號：DL-5996
品名：甜甜圈模 (心型6取)
規格：26 x 18 x 3.4 cm



型號：DL-5997
品名：甜甜圈模 (圓型12取)
規格：26 x 18 x 2.4 cm



型號：DL-5998
品名：甜甜圈模 (波堤6取)
規格：26 x 18 x 2.4 cm



型號：DL-6035
品名：無底圓型蛋糕模 (3入)
規格：最大 18 x 4.5 cm



型號：DL-6036
品名：底盤可脫披薩盤
規格：18 x 18 x 2 cm



型號：DL-6037
品名：底盤可脫披薩盤
規格：21.6 x 21.6 x 2 cm



型號：DL-6039
品名：底盤可脫長型派模
規格：20 x 8 x 3.1 cm



型號：DL-6040
品名：棒棒糖模 (球型)
規格：20 x 20 x 3.5 cm



型號：DL-6042
品名：棒棒糖模 (心型)
規格：21.5 x 17.5 x 4 cm



型號：DL-6043
品名：甜甜圈模 (心、波堤、圓花)
規格：26 x 17.8 x 2.4 cm



型號：DL-6044
品名：貝殼蛋糕模 16取
規格：26 x 17.8 x 1 cm



型號：DL-6045
品名：玫瑰蛋糕模 15 取
規格：26 x 18 x 2.5 cm




型號：DL-6118
品名：15 cm 底部可取方型蛋糕模
規格：16.1 x 16.1 x 4.6 cm



型號：DL-6119
品名：18 cm 底部可取方型蛋糕模
規格：19.2 x 19.2 x 4.7 cm




型號：DL-6132
品名：不沾烤盤
規格：30 x 22 x 2.5 cm



型號：DL-6139
品名：18 cm 方型不沾派盤
規格：18 x 18 x 3.1 cm



型號：DL-6149
品名：12 cm 底盤可脫式派盤
規格：12 x 12 x 2.6 cm



型號：DL-6150
品名：15 cm 底盤可脫式派盤
規格：15 x 15 x 3 cm



型號：DL-6151
品名：18 cm 底盤可脫式派盤
規格：18 x 18 x 2.6 cm



型號：DL-6152
品名：21 cm 底盤可脫式派盤
規格：21 x 21 x 3 cm



型號：DL-6164
品名：底部可脫細長蛋糕模 ST
規格：5.7 x 27 x 4 cm



型號：DL-6263
品名：糖粉篩
規格：18.3 x 7.5 x 3.5 cm




型號：DL-6294
品名：矽膠刮平刀
規格：29 x 6.5 x 1 cm



型號：DL-6309
品名：廣底料理盆 (21 cm)
規格：23.1 x 23.1 x 12 cm



型號：DL-6310
品名：廣底料理盆 (24 cm)
規格：26.5 x 26.5 x 11.5 cm



型號：DL-6401
品名：正方形餅乾模 (3 入)
規格：14 x 9.5 x 2.5 cm 外包裝



型號：DL-6402
品名：橢圓型餅乾模 (3 入)
規格：14 x 9.5 x 2.5 cm 外包裝



型號：DL-6403
品名：圓型餅乾模 (3 入)
規格：14 x 9.5 x 2.5 cm 外包裝



型號：DL-6404
品名：星型餅乾模 (3 入)
規格：14 x 9.5 x 2.5 cm 外包裝



型號：DL-6405
品名：雪花型餅乾模 (3 入)
規格：14 x 9.5 x 2.5 cm 外包裝



型號：DL-7006
品名：螺旋麵包矽膠模 4 取
規格：13.4 x 11.2 x 14.2 cm



型號：DL-7007
品名：半圓麵包矽膠模 3 取
規格：12.8 x 11.4 x 14.2 cm



型號：DL-7008
品名：菠蘿麵包花紋壓模
規格：12 x 12 x 2.7 cm



型號：DL-7010
品名：漢堡烤模 (2 入)
規格：10.8 x 10.8 x 2.5 cm



型號：DL-7011
品名：熱狗堡烤模 (2 入)
規格：7.1 x 19 x 26 cm



型號：DL-7012
品名：正方形吐司模
規格：18.5 x 18.5 x 12.8 cm



型號：DL-7013
品名：帽型吐司模
規格：15.1 x 15.1 x 9.5 cm



型號：DL-7014
品名：愛心吐司模
規格：15.1 x 15.1 x 9.5 cm



型號：DL-7015
品名：小熊吐司麵包烤模
規格：15.1 x 15.1 x 9.5 cm



型號：DL-7510
品名：糕點塑形工具棒 9 支組
規格：16.5 x 15.5 x 2 cm 外包裝




型號：DL-8000
品名：立體南瓜蛋糕模 (3 取)
規格：26 x 18 x 3.3 cm



型號：DL-8001
品名：可愛南瓜餅乾壓模組
規格：7.2 x 8.2 x 1.8 cm



型號：DL-8002
品名：動物友好餅乾壓模組
規格：6.4 x 9.2 x 1.8 cm



型號：DL-8003
品名：交通工具餅乾壓模組
規格：9.6 x 6.5 x 1.8 cm



型號：DL-8004
品名：萬聖節餅乾壓模組
規格：17 x 13.2 x 1.3 cm 含包裝



型號：DL-8005
品名：幸運兔餅乾壓模組
規格：17 x 13.2 x 1.3 cm 含包裝



型號：DL-8006
品名：森林熊餅乾壓模組
規格：17 x 13.2 x 1.3 cm 含包裝



型號：DL-8007
品名：萬聖節棒棒糖矽膠模
規格：26 x 10 x 2 cm



型號：DL-8008
品名：動物棒棒糖矽膠模
規格：26 x 10 x 2 cm



型號：DL-8009
品名：玫瑰草莓棒棒糖矽膠模
規格：26 x 10 x 2 cm



型號：DL-8016
品名：聖誕老人餅乾壓模組
規格：7.6 x 7.4 x 1.8 cm



型號：DL-8017
品名：愛心蝴蝶結餅乾壓模組
規格：7 x 8.5 x 1.8 cm



型號：DL-8018
品名：雪人餅乾壓模組
規格：17 x 13.2 x 1.3 cm 含包裝



型號：DL-8019
品名：甜心熊餅乾壓模組
規格：17 x 13.2 x 1.3 cm 含包裝



型號：DL-8020
品名：聖誕棒棒糖矽膠模
規格：26 x 10 x 2 cm



型號：DL-8022
品名：風呂熊巧克力矽膠模
規格：18 x 14 x 2.4 cm



型號：DL-8023
品名：風呂動物巧克力矽膠模
規格：18 x 11 x 3.1 cm



型號：DL-8063
品名：風呂企鵝巧克力矽膠模
規格：18.2 x 11.1 x 2.8 cm



型號：DL-8064
品名：熊抱巧克力矽膠模
規格：18 x 11 x 1.6 cm



型號：DL-8028
品名：愛心圓花翻糖模(3枚入)
規格：12.5 x 10 x 0.3 cm



型號：DL-8029
品名：小花裝飾翻糖模(3枚入)
規格：12.5 x 10 x 0.3 cm



型號：DL-8032
品名：雪人翻糖模(3枚入)
規格：12.5 x 10 x 0.3 cm



型號：DL-8033
品名：聖誕老人翻糖模(3枚入)
規格：12.5 x 10 x 0.3 cm



型號：DL-8034
品名：甜心貓翻糖模(3枚入)
規格：12.5 x 10 x 0.3 cm



型號：DL-8035
品名：帽子汽車翻糖模(3枚入)
規格：12.5 x 10 x 0.3 cm



型號：DL-8036
品名：夾子湯匙擠花袋工具組
規格：20.5 x 13.2 x 2 cm 外包装



型號：DL-8038
品名：糖心餅乾壓模(撲克牌)
規格：17 x 13 x 5 cm 外包装



型號：DL-8039
品名：糖心餅乾壓模(甜心鑰匙)
規格：17 x 13 x 5 cm 外包装



型號：DL-8040
品名：6個連圓型餅乾模
規格：13.5 x 9.1 x 1.9 cm



型號：DL-8041
品名：8個連心型餅乾模
規格：13.5 x 9.1 x 1.9 cm



型號：DL-8042
品名：小圓點糖粉飾(2枚入)
規格：17 x 11 x 0.2 cm



型號：DL-8043
品名：愛心糖粉飾(2枚入)
規格：17 x 11 x 0.2 cm



型號：DL-8044
品名：豹紋糖粉飾(2枚入)
規格：17 x 11 x 0.2 cm



型號：DL-8045
品名：雪花糖粉飾(2枚入)
規格：17 x 11 x 0.2 cm



型號：DL-8060
品名：萬聖節餅乾模 + 翻糖模組
規格：17 x 20 x 1.3 cm 外包装



型號：DL-8061
品名：雪人餅乾模 + 翻糖模組
規格：17x20x1.3 cm 外包裝



型號：DL-8062
品名：甜心熊餅乾模 + 翻糖模組
規格：17x20x1.3 cm 外包裝



型號：DL-8046
品名：18 cm 輕鋁中空天使蛋糕模
規格：19.6 x 19.6 x 4.2 cm



型號：DL-8047
品名：18 cm 輕鋁方型蛋糕模
規格：19.7 x 21 x 4.8 cm



型號：DL-8048
品名：17x8cm 輕鋁長型蛋糕模
規格：18.4 x 9.2 x 5.4 cm



型號：DL-8049
品名：20x8cm 輕鋁長型蛋糕模
規格：22.2 x 9.2 x 5.8 cm



型號：DL-8050
品名：12 cm 輕鋁底可取派模
規格：14.2 x 14.2 x 2.9 cm



型號：DL-8051
品名：16 cm 輕鋁底可取派模
規格：18 x 18 x 2.9 cm



型號：DL-8052
品名：19 cm 輕鋁底可取派模
規格：20.9 x 20.9 x 3.2 cm



型號：DL-8053
品名：22 cm 輕鋁底可取派模
規格：24.4 x 24.4 x 3.2 cm



型號：DL-8054
品名：12 cm 輕鋁底可取蛋糕模
規格：12.5 x 12.5 x 5.1 cm



型號：DL-8055
品名：15 cm 輕鋁底可取蛋糕模
規格：15.6 x 15.6 x 6.1 cm



型號：DL-8056
品名：18 cm 輕鋁底可取蛋糕模
規格：18.7 x 18.7 x 6.1 cm



型號：DL-8057
品名：21 cm 輕鋁底可取蛋糕模
規格：21.7 x 21.7 x 6.1 cm




型號：DL-8058
品名：19x27cm 輕鋁長方烤盤
規格：30 x 22 x 2.5 cm




型號：DKT-24
品名：電子秤附時鐘
規格：19 x 16 x 4.5 cm



型號：DL-9000
品名：電子秤(白/2kg)
規格：23.6 x 17.5 x 3.6 cm



型號：SJ1455
品名：50x40cm 揉麵矽膠軟墊
規格：50 x 40 x 0.1 cm



型號：YJ1506
品名：彩繪蛋糕矽膠墊(動物)
規格：30 x 30 x 0.1 cm



型號：DL-6055
品名：杯子 + 餅乾模組



型號：DL-6056
品名：方型蛋糕模組
規格：5x5CM



型號：DL-6057
品名：派用滾輪刀模具組



型號：DL-6058
品名：迷你吐司蛋糕模組
規格：8 個取



型號：DL-6059
品名：湯匙型矽膠模組
規格：8 個取



型號：DL-6060
品名：馬卡龍模花嘴組