



型號：FP-1000
品名：可調整麵包切片架
規格：17.3x14.5x4 cm



型號：FP-5018
品名：愛心餅乾模(3入)
規格：6.9 x 5.6 x 1.8 cm




型號：FP-5022
品名：俏皮愛心餅乾模(3入)
規格：7 x 5.4 x 1.8 cm




型號：FP-5206
品名：可愛布丁模組 4入
規格：7.5 x 7 x 6.5 cm



型號：FP-5208
品名：甜甜圈模
規格：26x17.9x2.3 cm




型號：FP-5212
品名：立體餅乾模(熊/兔)
規格：14.5 x 11 x 5.2 cm



型號：FP-5213
品名：立體餅乾模(飛機/螃蟹)
規格：14.5x11x5.2 cm



型號：FP-5215
品名：可愛造型蛋糕模(藍)
規格：15 x 15 x 4 cm



型號：FP-5222
品名：寒天果凍模 / 壓條器組
規格：17.5x18.5x5 cm



型號：FP-5360
品名：立體圓球動物巧克力模
規格：17.9 x 17.9 x 2.5 cm



型號：FP-5361
品名：可愛熊巧克力模(12取)
規格：13.5 x 17.9 x 2 cm



型號：FP-5363
品名：蝴蝶結巧克力模(16取)
規格：17.9 x 17.9 x 1.5 cm



型號：FP-5381
品名：蛙蛙矽膠巧克力模(12取)
規格：18x13.5x1.8 cm



型號：FP-5383
品名：兔兔矽膠巧克力模(12取)
規格：18 x 13.5 x 1.7 cm



型號：FP-5384
品名：小豬矽膠巧克力模(12取)
規格：18x13.5x1.6 cm



型號：FP-5395
品名：菊型鋼圈粉飾
規格：4 x 4 x 2 cm



型號：FP-5396
品名：愛心鋼圈粉篩
規格：4 x 4 x 2 cm



型號：FP-5397
品名：方型花邊鋼圈粉篩
規格：3.6 x 3.6 x 2 cm



型號：FP-5398
品名：熊型鋼圈粉篩
規格：5 x 5 x 2 cm



型號：FP-5399
品名：圓花邊矽膠模 9 個取
規格：8 x 8 x 1.8 cm



型號：FP-5400
品名：愛心矽膠模 9 個取
規格：8 x 8 x 1.8 cm



型號：FP-5401
品名：方型花邊矽膠模 9 個取
規格：8 x 8 x 1.8 cm



型號：FP-5402
品名：迷你瑞士捲矽膠模 6 個取
規格：30.2 x 16.5 x 2.2 cm



型號：FP-5150
品名：奶油切割器收納盒(咖啡)
規格：16.5 x 9.5 x 6.8 cm



型號：FP-5371
品名：夾子
規格：19 x 5 x 5 cm