



75893
23cm



76089
23cm



76306
25cm



76364
25cm



76391
25cm



76392
23.5cm



76564
25cm



BS-250
蟹剪(附蟹叉2支)
25.5cm



DA-0407
22x9.5x1cm



EA-230
13.5x8.5x0.5cm



MA-20
20.5cm



SK-8
多功能8合1
廚房剪刀附套



SUM-1400
攜帶用食物剪(袋裝)
16x7.2x0.8cm



SUM-1400HC
攜帶用食物剪(盒裝)
16x7.2x0.8cm



DH-2721
貓咪廚房剪刀附蓋
17.1x7.3x1.7cm



DH-2739
貓咪廚房剪刀附蓋(白)
17.1x7.3x1.7cm



DH-3005
21.3cm



DH-3139(附蓋黑色)
19.5x7.5x1cm



DH-3311
關孫六廚房剪刀(厚刃)
21.2x9.2x1.4cm



DH-3312
關孫六短刃廚房剪刀
18.7x9x1cm



DH-3313
關孫六曲線廚房剪刀
23x10x1.2cm



DH-3344
關孫六廚房剪刀(厚刃加長)
23.2x9.2x1.4cm



DH-3345
關孫六鍛造廚房剪刀(柄ST)
20.7x7.5x1.2cm



DH-3346
關孫六鍛造曲線剪刀(柄ST)
22x7.5x1.2cm



DH-3347
關孫六曲線廚房剪刀(附套/S)
16.6x7x1cm



DH-3348
關孫六廚房剪刀附蓋(黑)
16x8.9x1cm



DH-3353
關孫六廚房剪刀
19.5x9x1.2cm



DH-3354
關孫六曲線廚房剪刀
19.5x9x1.2cm



DH-8000
廚房剪刀(P型)
22.2x9x1.5cm



DH-8001
廚房剪刀
19x8x1cm



DH-8002
可拆式曲線廚房剪刀(白)
16.6x7x1cm

廚房剪刀、辦公剪刀



DH-8003
可拆式曲線廚房剪刀(綠)
16.6x7x1cm



DH-8004
廚房剪刀
19.3x8.6x1cm



DH-8005
廚房剪刀(灰)
21.2x8.6x1cm



DH-8006
廚房剪刀附磁吸盒
22x8.5x4cm



DOU JING

DM-7240
旬廚房剪刀
22.8x8.9x1.3cm



SC-2020
全不鏽鋼廚用剪刀
20.3x8.2x0.8cm



041BP0023
料理剪刀附套(黑)



041BP0024
料理剪刀附套(白)



718908
附套迷你剪(紅色)
10.4x5.3x1.2cm



718922
附套迷你剪(黃色)
10.4x5.3x1.2cm



718939
附套迷你剪(綠色)
10.4x5.3x1.2cm



718960
附套迷你剪(粉色)
10.4x5.3x1.2cm



718991
附套迷你剪(紫色)
10.4x5.3x1.2cm



9350
迷你磁鐵剪刀
8.7x4.4x1.1cm



9354
迷你磁鐵剪刀
8.7x4.4x1.1cm



FG-5188
料理小剪刀+夾子
24x9x1.1cm



N5135
事務剪
13.5cm



N5135C
事務剪
13.5cm



N5165
事務剪
16.5cm



N5210
事務剪
21cm



BT220N
9" 玉三郎裁縫剪刀ST
22cm



BT240N
10" 玉三郎裁縫剪刀ST
24cm



HCB240
鑽石剪刀ST
24cm



HCB260
鑽石剪刀ST
26cm



S-100
10" 庄三郎剪刀(紅盒)
24cm



S-110
11" 庄三郎剪刀(紅盒)
28cm



S-120
12" 庄三郎剪刀(紅盒)
30cm



SS-100
10" 庄三郎剪刀ST
24cm



041LH0046
10.5" 庄三郎剪刀(黑盒)
26cm



041LH0047
11" 庄三郎剪刀(黑盒)
28cm



PK-2800
特級布樣剪
23cm



PK-3200
布樣剪(大把手)
23cm



114010
大理裁縫剪刀
24cm



31500
10"秀兼剪刀
24cm



31502
11"秀兼剪刀
28cm



7205
專業布剪
20.5cm



7230
專業布剪
23cm



7240AS
專業布剪(微鋸齒)
24cm



7250
專業布剪
25cm



7250SE
專業布剪
25cm



7250SL
專業布剪(輕便型)
25cm



7280
專業布剪
28cm



7280SE
專業布剪(細齒)
28cm



7300
專業布剪
30cm